

## Codici / Codes

## OVOLUX STEADY\*







Luca fissa con lampada a filamento  
Steady light with incandescent bulb  
Feu fixe, ampoule à incandescence

							
BASES R	12/240V ACDC	30011	30012	30013	30014	30015	30016
M	12/240V ACDC	30031	30032	30033	30034	30035	30036

\* Fornito senza lampada / Supplied without bulb / Fourni sans ampoule

## OVOLUX FLASHING\*








Luca lampeggiante con lampada a filamento  
Flashing light with incandescent bulb  
Feu clignotant avec ampoule à incandescence

							
BASES R	12/48V DC	30051	30052	30053	30054	30055	30056
	24/240V AC	30091	30092	30093	30094	30095	30096
M	12/48V DC	30071	30072	30073	30074	30075	30076
	24/240V AC	30111	30112	30113	30114	30115	30116

\* Fornito senza lampada / Supplied without bulb / Fourni sans ampoule








## OVOLUX LED

Luca multifunzione a LED  
LED multifunctional light  
Feu multifonction à LED

							
BASES R	12/24V ACDC	38781	38782	38783	38784	38785	38786
	90/240V AC	38791	38792	38793	38794	38795	38796
M	12/24V ACDC	38801	38802	38803	38804	38805	38806
	90/240V AC	38811	38812	38813	38814	38815	38816

## OVOLUX X\*

Luca allo Xenon  
Flashing light with Xenon discharge tube  
Feu au Xénon


							
BASES R	24V ACDC	30131	30132	30133	30134	30135	30136
	110V AC	30171	30172	30173	30174	30175	30176
	240V AC	30211	30212	30213	30214	30215	30216
M	24V ACDC	30151	30152	30153	30154	30155	30156
	110V AC	30191	30192	30193	30194	30195	30196
	240V AC	30231	30232	30233	30234	30235	30236

\* Fornito con lampada / Supplied with bulb / Fourni avec ampoule

## RICAMBI CUPOLE / SPARE DOMES / DOMES DE RECHANGE

						
	71115	71116	71117	71098	71099	71100

## ACCESSORI / ACCESSORIES / ACCESSOIRES

	
OVOLUX MOUNTING ADAPTER	27697
WALL MOUNT	27762
DOUBLE WALL MOUNT	27763
EXTENDED FOOT L10	27764

# ACCESSORI ACCESSORIES ACCESSOIRES



OVOLUX MOUNTING ADAPTER


## OVOLUX MOUNTING ADAPTER

ADATTATORE (necessario per utilizzare gli accessori)  
ADAPTER (to mount the accessories)  
ADAPTATEUR (nécessaire pour utiliser les accessoires)

Codici / Codes

OVOLUX MOUNTING ADAPTER

27697



EXTENDED FOOT L10


## EXTENDED FOOT L10

Base piana per montaggio superficiale con estensione di 10 cm  
Flat base for surface mount with 10 cm extension  
Base pour montage à plat (position soulevée de 10 cm)

Codici / Codes

EXTENDED FOOT L10

27764



WALL MOUNT


## WALL MOUNT

Base parete per montaggio laterale  
Wall base for side mount  
Support fixation en applique (à filetage simple)

Codici / Codes

WALL MOUNT

27762



DOUBLE WALL MOUNT

## DOUBLE WALL MOUNT

Base parete per montaggio laterale di 2 dispositivi  
Wall base for side mount of 2 devices  
Support fixation en applique (à double filetage) pour 2 dispositifs

Codici / Codes

DOUBLE WALL MOUNT

27763

